



CARRON
P H O E N I X

Punching a Tap Hole in a Granite Sink

IMPORTANT

PRIOR TO knocking out your tap hole, your sink should be placed in your worktop.

- 1 Ensure the colour sticker on your sink is located centrally of the pre-drilled tap hole.
- 2 Place your sink into your worktop.
- 3 Take a centre punch and place the point in the centre of the coloured sticker.
- 4 Strike the punch hard with a hammer. This will result in the core of the tap hole to be knocked out.
- 5 Finish off the tap hole using a hammer and a round file.